If you are using a printed copy of this procedure, and not the on-screen version, then you <u>MUST</u> make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A

### C-A OPERATIONS PROCEDURES MANUAL

#### **ATTACHMENT**

#### 4.120.42.c Switch Yard Crash Tests

C-A-OPM Procedures in which this Attachment is used.					
4.120.42					

## **Hand Processed Changes**

HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>	
		Signature on File	<del>-</del> -	<del>-</del> <del>-</del> -
	C.O.	llider-Accelerator Departr	nent Chairman	Date

V. Castillo

# 4.120.42.c Switch Yard Crash Tests

### PASS ANNUAL ACCEPTANCE TEST PROTOCOL

Division A Software Filename and Checksum: Title:	Checksum:				
Division B Software Filename and Checksum: Title:	Checksum:				
<u>Initial testing complete</u> :					
Test Team Leader's Name (Print):	Life Number:				
Test Team Leader's Name (Sign):	Date:/				
Acceptance test procedure complete (following repairs and retesting if required):					
Test Team Leader's Name (Print):	_ Life umber:				
Test Team Leader's Name (Sign):	<b>Date:</b> /				
Test results reviewed by:					
Safety Section Head's Name (Print):	Life Number:				
Safety Section Head's Name (Sign):	Date:/				
Test results accepted by Radiation Safety Committee:					
RSC Member's Name (Print):	Life Number:				
RSC Member's Name (Sign):	Date:/				

# 1.1 Test of Crash Buttons (CB) System

PRESS	Crash Button to activate crash	
VERIFY VERIFY	MCR sees on Opto monitor primary crash MCR sees on Opto monitor redundant crash	INTERLOCK INTERLOCK
VERIFY	MCR attempt to reset crash hardware at Panel Y	FAIL
RETRACT	Crash Button to start <b>RESET</b>	
VERIFY	MCR attempt to reset crash hardware at Panel Y	SUCCESSFUL
VERIFY VERIFY	MCR sees on Opto monitor primary crash MCR sees on Opto monitor redundant crash	OK OK
PRESS	Hit Return for software reset at Opto monitor	
VERIFY	MCR sees on Opto monitor crash	OK
FOLLOW	Table 1 below	

3

Crash Button Location		Crash locn		ICR sees at sh interlock	Reset Hware at MCR FAIL	Retract Crash Button	Reset Hware at MCR OK	Verify MCR sees at locn crash button ok		Hit Return to Reset	Verify MCR sees at locn
			Prim	Redun				Primary	Redundant	Sware at MCR	crash ok
Switch Yard	CB 1										
"	CB2										
66	CB3										
66	CB4										
66	CB5										
66	CB6										
66	CB7										
D6 Separátor 1	CB8										
D6 Separtitor 2	CB9										
A Target	CB1										
66	CB2										
66	CB3										
"	CB4										

**Table 1 – Test of Crash Buttons** 

☐ Check for acceptance of Test of Crash Buttons System

## END OF TEST PROCEDURE

TTL: Sign for completion of initial testing:		_
	Date://	
TTL: Sign for completion of final testing:		
	Date· / /	