

*If you are using a printed copy of this procedure, and not the on-screen version, then you **MUST** make sure the dates at the bottom of the printed copy and the on-screen version match. The on-screen version of the Collider-Accelerator Department Procedure is the Official Version. Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ Training Office, Bldg. 911A.*

C-A OPERATIONS PROCEDURES MANUAL

12.17 Shut Down Before Power Outage

Text Pages 2 through 4

Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: _____ ***Signature on File*** _____
 Collider-Accelerator Department Chairman Date

M. Wiplich

12.17 Shut Down Before Power Outage

1. Purpose

The purpose of this procedure is to protect electrical and electronic equipment from sudden and unsupervised startup after the power is restored. This is necessary for the vacuum system and a good idea for computers. Pumps should not come on unsupervised after a shutdown since the degree of vacuum spoilage will be unknown.

2. Responsibilities

It is the responsibility of the person or persons executing this procedure to observe all safety rules.

3. Prerequisites

3.1 Tandem Operator training

4. Precautions

None

5. Procedure

Checklist (when indicated by “___”, initial step upon completion)

- 5.1 ___ Power off all cryo compressors and heads, valve closed.
- 5.2 ___ Back fill ion source with ultra pure argon.
- 5.3 ___ Power off all ion pumps, valve open.
- 5.4 ___ Close machine gate valves.
- 5.5 ___ Close all vacuum valves in TtB sections 10 thru 13.
- 5.6 ___ Turn off all 303 controllers in TtB sections 10 thru 13.
- 5.7 ___ Ignore all TtB faraday cups and harps.
- 5.8 ___ Valve off air to TtB.

- 5.9 ____ Sensaphone off.
- 5.10 ____ Turn off Plectron to save batteries.
- 5.11 ____ Abort halon.
- 5.12 ____ All other equipment off.
- 5.13 ____ Chilled water pump off.
- 5.14 ____ Deionized water pumps off.
- 5.15 ____ SF6 Gas Panel - HCV valves closed, lock valves key switch.
- 5.16 ____ D1 power supply - disconnect IEEE cable and turn off.
- 5.17 ____ TR-4 computers (PCs and HP) and all equipment off.
- 5.18 ____ Close beam line valves TR-2 & TR-4.
- 5.19 ____ 303 controller in TR-4 off.
- 5.20 ____ Turn off racks TR-4.
- 5.21 ____ Both Miran systems off.
- 5.22 ____ Computers and monitors off. See list.
- 5.23 ____ TR-1 computer off.
- 5.24 ____ TR-2 computer off.
- 5.25 ____ Control room computers off (4).
- 5.26 ____ Apollo computer and video off.
- 5.27 ____ Lab 1 Vladimir's computer off.

5.28 The following items are only done if it is known that TtB power will go off.

5.28.1 ____ Close all vacuum valves in TtB.

5.28.2 ____ Turn off all 303 controllers in TtB.

5.28.3 ____ Ignore all TtB faraday cups and harps.

6. Documentation

The “ ____ ” (lines) in the procedure are for place-keeping only. This procedure is not a record.

7. References

None

8. Attachments

None