If you are using a printed copy of this procedure, and not the on-screen version, then you <u>MUST</u> make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.

Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ

Training Office, Bldg. 911A.

Hard copies of all s		erating Procedures are kep Office, Bldg. 911A.	ot on file in the C-A ESHQ
	C-A OPERATION	S PROCEDURES MANU	JAL
	12.37 Transfer C	Gas from MP-6 to East Ba	nk
	Text F	ages 2 through 4	
	<u>Hand P</u>	rocessed Changes	
HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>
		der Accelerator Departm	ent Chairman Date
Collider-Accelerator Department Chairman			

M. Wiplich

#### 12.37 Transfer Gas from MP-6 to East Bank

# 1. <u>Purpose</u>

The purpose of this procedure is to define the sequence of activities required to transfer SF6 gas mix from MP-6 to the East Bank storage tanks.

# 2. Responsibilities

It is the responsibility of the person or persons executing this procedure to observe all safety rules.

# 3. <u>Prerequisites</u>

The person or persons executing this procedure shall have all formal training required of a TVDG Operator.

# 4. <u>Precautions</u>

None

## 5. <u>Procedure</u>

- 5.1 Preliminary activities:
  - 5.1.1 Insure that both LE and HE Vacuum Gauges are ON and zeroed.
  - 5.1.2 Turn Chart Recorders ON and Record DATE and TIME on chart.
  - 5.1.3 Record Storage & Both Tank Pressures on Pumpout Log Sheet.
  - 5.1.4 Set MIRAN System to NORMAL (all channels ON, HOLD OFF).
  - 5.1.5 In the gas house OPEN the three EAST BANK isolation valves.
- 5.2 Set Air Control Valve HOV-47 to Empty
- 5.3 Close HCV-27, Verify that HCV-53 & FCV-1 are Closed. Leave HCV-23 Open.
- 5.4 In the Pit below MP-6:
  - 5.4.1 Close 4 Cold Water Valves.
  - 5.4.2 Open 4 Hot Water Valves.

- 5.4.3 Unlock and Open V-51 (valve will be closed again in step 7).
- 5.4.4 Unlock and Open HOV-29 (located on the South Wall near MP-6 HE End).
- 5.5 Open PCV-1, HOV-11, HOV-8, HOV-9 & HOV-15 in order to get Compressors into Bypass and to equalize pressure across HCV-29.
- 5.6 Open HCV-29 when its Differential Pressure Gauge reads 0.
- 5.7 Close and Lock V51 in the Pit below MP-7. Remove the key and insert it into the corresponding lock on the LE MP-6 Manway Door.
- 5.8 Turn the Recirculator ON.
- 5.9 Turn the Hot Water Pump (J- 130) ON and Open the Hot Water Valve.
- 5.10 If the MP-6 Tank Pressure is higher than the West Bank Storage Pressure, then Open HOV-10 to allow gas to free-flow from MP-6 to the West Bank. Record Time, Tank Pressure, LE Vac and HE Vac on Pumpout Log Sheet.
- 5.11 Open Water Supply Valves on Both Compressors.
- 5.12 Verify that both Compressor Output Valves V-4 & V-6 are Open. Crack Open Input Valves V-3 & V-5 about 10%.
- 5.13 When the Tank-to-Storage Pressure difference is less than or equal to 100 PSI or if Storage Pressure is higher than MP-6 Tank Pressure, then turn both Compressors ON (one at a time). Record Compressor Starting Time, Tank Pressure, LE Vac, HE Vac and Storage Pressure on Pumpout Log Sheet.
- 5.14 Close HOV-8 & Open HOV-10. MP-6 is now being pumped out as well as the gas line out to V-51. Adjust the Compressor Input Valves V-3 & V-5 for a Compressor Input Pressure of 125 PSI MAXIMUM. (This pressure may be read on the gauges above V-3 and V-5)
- 5.15 To have the Tank emptied as soon as possible, keep Opening V-3 & V-5 to maintain the Compressor Input Pressure at 125 PSI.

# <u>Caution:</u> !!! Do Not Exceed 125 PSI !!!

Well before the Tank Pressure is down to 0 PSI, evacuate and backfill the Vacuum Pumps and Vacuum Lines between HCV-1 and HCV-2 with SF6 mix as follows:

3

- 5.16.1 Select Vacuum Pump Output HCV-54 for Exhaust.
- 5.16.2 Open HCV-31.
- 5.16.3 On SF6 Control Panel, set Pressure Controller PCV-33 to Valve and Manual and turned Wide Open.
- 5.16.4 Set both Blower Switches to OFF.
- 5.16.5 Close V-45A (Vacuum Pump Vent Valve).
- 5.16.6 Turn Vacuum Pump (J- 105) ON. In a very short time the pressure should be down to 30" as read on the gauges directly above V-45B (near valve HCV-31).
- 5.16.7 Turn Vacuum Pump OFF.
- 5.16.8 Select HCV-55 for SF6 Recovery.
- 5.16.9 Open V-45B to backfill this line and the Vacuum Pumps with SF6 mix.
- 5.16.10 Close V-45B when the gauges above V-45B read 0 PSI. Note that Vacuum Lines filled with SF6, on Check Sheet.
- 5.17 When the above steps are completed, but before the Tank Pressure is down to 0 PSI, Prepare for Vacuum Pumping:
  - 5.17.1 Verify that Vent Valves V-45A & V-45B are Closed.
  - 5.17.2 Verify that both Blower Switches are OFF.
  - 5.17.3 Open Water Cooling Valve on SF6 Recovery Heat Exchanger (Valve is located over head to right of Gas Panel and has a dark blue handle).
  - 5.17.4 Verify that HCV-55 is set for SF6 Recovery.
- 5.18 When Tank Pressure is 0 PSI on the MP-7 Tank-to-Atmosphere Differential Pressure Gauge, Proceed to <u>Vacuum Pumping MP6 SF6</u>. Record Time, Tank Pressure, LE Vac, HE Vac and Storage Pressure on Pumpout Log Sheet.

## 6. <u>Documentation</u>

None

#### 7. References

None

## 8. Attachments

None